

LEFT SIDE CABINET
LINKE KORPUS SEITE

i

G1x H1x L1x M2x 3mm

A4x Ø4x15mm
B8x Ø4x20mm
C2x Ø5x8mm
D4x Ø4x24mm
E2x
F2x
I1x
N1x

GARBO 45-2	8 ft.	12 ft.	12 ft.	18 ft.
GARBO 50-3	1x	1x	1x	1x
GARBO 60-3	1x	1x	1x	1x
GARBO 60-4	2x		2x	

1

16mm

CLICK

L

19mm

F

TO REMOVE FRAME
RAHMEN
ENTFERNEN

PUSH

2

CABINET DRILLING / KORPUS BOHRUNG

TEMPLATE
SCHABLONE

FOLD 90°
FALTEN 90°

USE THE BLACK HOLES
SCHWARZE LÖCHER NUTZEN

REPEAT THE OPERATIONS ON RIGHT SIDE
SPIEGELBILDICH WIEDERHOLEN

3

4

CLICK

5

DOOR DRILLING / TÜRBOHRUNG

USE THE RED HOLES
ROTE LÖCHER NUTZEN

X = DOOR WIDTH
X = TÜRBREITE

ALIGN THE TEMPLATE CENTERED ON
THE BOTTOM OF DOOR
SCHABLONE UNTEN MITTIG ANLEGEN

FOR X = 800MM
FOR X = 850MM
FOR X = 900MM
FOR X = 950MM
FOR X = 1000MM

BOTTOM DOOR
TÜR UNTERKANTE

6

x4

A

7

COVER HOLDER
HALTER DECKELPLATTE

D x4

8

1

2

3

x2

C

9

DOOR ADJUSTMENT / TÜR EINSTELLUNGEN

10

1

2

G

11

M

x2

12

N

KORPUSINNENECKE /
TÜR UNTERKANTE
BOTTOM CABINET /
BOTTOM DOOR